



Home Karaoke Ltd since 1991
(Canada's FIRST Karaoke Store)

4559 Sheppard Ave #A
Scarborough, ONT, M1S 1V3

Tel: 416-291-3121
E-mail: homekaraoke@hotmail.com
Web: www.homekaraoke.ca

If You Want to Sing We Have What You Need ! (Do You Know What You Need ?)



Written by
Andrew CHENG
August, 2022

Contents

Chapter 1	<i>If You Want to Sing, We Have What You Need</i> <i>Online Free Shipping Policy</i>	P3-4
Chapter 2	<i>Goodbye to “Disc” and “Song Chip”</i> <i>(Karaoke Machine go “Digital”)</i>	P5
Chapter 3	<i>Karaoke Sound System</i> <i>and</i> <i>Karaoke Machine Upgrading Policy</i>	P6-7
Chapter 4	<i>Microphones</i> <i>(Corded & Wireless Mic System)</i> <i>and</i> <i>Technical Support & Repairing Services</i>	P8-10
Chapter 5	<i>Set Up Your Karaoke System Now</i> <i>(How to search for your suitable</i> <i>karaoke product on site)</i>	P11
Chapter 6	<i>Warranty, Return & Exchange Policy</i>	P12

Chapter 1

If you want to sing, we have what you need

To sing, we need 3 things. **First is your music.** What you need is some kind of a “Player” to play out your music.

“Music Player” can be your cell phone or I-Pad, or, recently, your smart TV with Youtube playing out your music.

In the case of singing with music from your smart TV, all you need is a **Karaoke Amp/Speaker System, built-in with Microphone Inputs, digital Echo adjustment and Bluetooth.** Furthermore, because TV sound is digital without bass, you need a “Digital to Analog” converter to connect TV digital sound to analog for singing.

However, if you are a DJ, hosting parties or you need something as a Home Entertainment Unit for your family and friends, you will need a “**Karaoke Machine**”. A “Karaoke Machine” is an A/V Player, responsible for “**Storing**” music as many as you want, able to “**Search**” your selected song fast, say, in just one second and to “**Play out**” the music of your media format.

Different languages of songs are designed and digitally recorded in different media formats according to their own evolution of karaoke development (Please refer to another booklet “Evolution of Karaoke Formats”). For example, for Chinese or Vietnamese songs, they are **MP4/MTV**, for Philippine, they are **AVI Real Sound Instrumental** and for English songs, they are in **AVA, CD+G or MP3+G**.

So, if you sing Chinese/Vietnamese songs, look for the “**2.1 Touch Screen Karaoke Machine**”, **Model No TS-2023**.

If you sing English songs only, look for the “**CD+G/MP3+G Karaoke Machine**”, **Model No DCU2017/8**.

If you are Filipino, look for the “**Philippine Special Karaoke Machine**”, **Model No SK-2021**.

Note: Watch Demo Videos of the above products on our site www.homekaraoke.ca

Online Free Shipping Policy

Free Shipping within Canada. For any order worth over \$299 before tax FREE shipping (limited to one parcel) is available for you.

For Free Shipping, your goods will be shipped out on standard delivery by Canada Post.

Chapter 2

Goodbye to “Disc” and “Song Chip” (Karaoke Machine go “Digital”)

Ten or more years ago, music are recorded in Compact Disc “CD” or “Song Chip”. They are obsolete now ! For 2 reasons ! First, whatever are recorded on a Disc or Chip, you cannot delete and if you want to sing other or new songs, you cannot add it in ! Second, the maximum data storage capacity of a Compact Disc is 4.7GB while the IC Song Chip is less. The “Song Chip Player”, that is, they call it “Magic Mic”, you have to keep on spending money to buy Song Chips for other songs at about \$80 each for about 200 songs which you may not like all of them.

*Karaoke Machines can now support Memory Card & USB up to 256GB. Because it is digital, we can write a firmware, like a “**Search Engine**” and other features. So, no matter how many thousands of songs in the Card or USB, you can go direct to search your selected song fast in just a second and play.*

*The second thing you need is a **Karaoke Sound System**. A Karaoke Machine plays out A/V signals only, and it makes no sound itself. We need some kind of a sound system to convert the “Audio Signals” to sound.*

A Sound System consists of an Amplifier with its Speakers of optimum matching power.

Chapter 3

Karaoke Sound System

Broadly speaking, there are two kinds of “Sound System”.

The first one I call it “**A/V Amplifier Sound System**”, designed for watching movies or listening to music, like sound from the TV or from Receiver, “Surround Sound” and “Movie Theatre” etc. These sounds are focused on clarity, with super high frequencies, no bass. They don’t have built-in “Microphone Inputs”. So, they are not designed for singing. If you really want to sing with such sound system, you need a “Mixer” for the purpose of Mic Input Jacks and/or Echo adjustment.

The other kind, I call it “**Karaoke Sound System**”. It is specially designed for singing. It is built-in with Mic Inputs and Echo adjustment. Now, judge the sound quality and quantity (Power Output) of the sound system by your own ear. For singing sound, the high note (Treble) should be “Clean and Clear” while the low note (Bass) must be Solid and Powerful! Also, the total Power Output of the Amplifier should match the handling capacity of the speakers.

That is why I always advise my customers to buy their “Karaoke Sound System” with their own ears. “**Listening is believing**” ! We have the lowest **Model No AS-2015/6**, up to our Best Seller, **Professional Portable Amplifier, Model No PAS-2022/3** and the **Professional Amplifier/Speakers** for performance standard, the latest **Model No KA-2023B** and **KA-2023G**.

Note: Watch Demo Videos of the above-said products.

Karaoke Machine Upgrading Policy

Simply, in the Trade-up, **you surrender your old machine** (obsolete model, broken or not, out of warranty or not, used a lot or not been used at all) and we **give you the latest machine**, brand new, direct from the factory and with one year warranty, **you just pay the difference** between the Current Sales Price of the new machine and a “ Buy Back Assigned Value, \$200 ” of your old machine.

Chapter 4

Microphones (Corded & Wireless Mic System)

*The third thing you need is the **Microphone**. Insert your microphone in the mic jack of your Karaoke Sound System and sing. Your vocal will be mixed and blended in with the song accompaniment. Broadly speaking, Microphones are of two kinds: Corded Mic and Wireless Mic.*

*For any mic, the most important part is the “**Pick-up head**”. A good “Mic pick-up” should be able to pick up your vocal, be it high or low pitch. A good mic should be able to withstand high Power Amplifier, too!*

*Next, it is the “**Mic Body**”. Different mics are different in shape and size. So, the wire connector cannot be expected to fit all types of “Mic Body”, and will surely leave a gap or a vacuum. If you sing and move, it makes noise, alien noise!*

*Lastly, it’s the **wire** ! It should be 100% copper! Copper is the best metal to transmit audio signal.*

*So, look for a **Pro. Mic with the “Locking Device” in the Mic Wire ! Model No P/M-2023, in Gold and Black colors.***

*Now, come to “**Wireless Mic**”. Unlike corded mic, it has no wire for vocal transmission! How is your vocal transmitted to the Amp then? Your vocal is transmitted through “RF Frequencies” in the air! The lowest band of Frequencies is your AM/FM in your radio. For example, if you turn on your radio, say FM88.5 MHz, somewhere in Barrie there is a broadcast station, broadcasting this Frequency. Your radio is the Receiver of that Frequency.*

So, if I give you just a wireless mic, FREE, it won’t work !

*A Wireless Mic is a **Transmitter of a built-in Frequency** and it should be Ultra High Frequency UHF, at least 400 to 800 MHz. Then, you need a “**Frequency Receiver**” built-in with the same Frequency. Normally, there is another Wireless Microphone with another Frequency. So, it is a “Wireless Microphone System”.*

*Professional Wireless Microphone Systems are built-in with 2000 selectable Frequencies and with a **Crystal Lock** to avoid Frequency slippage or disturbance.*

*Look for the **Professional Wireless Microphone System, latest Model No HKWM-2023.***

Chapter 4

Microphones (Corded & Wireless Mic System) (Continued)

Your vocal should be fully and naturally transmitted to the amplifier without any other noise with an operating distance of at least 300'ft.

*Note: Watch Demo Videos of the above products at our site
www.homekaraoke.ca*

Technical Support & Repairing Services

For repairing, customers must leave the defective product with us. 3-5 working days are required for our FREE inspection and repairing cost estimate. Customers will then be notified of the repairing cost. Subject to the approval of the customer, repairing will proceed. Repairing will take at lease 7 working days and NO courtesy machine will be on loan to the customers.

*Should the customers any decide not to repair, he/she should come and take back and other accessories that are left with us **WITHIN A MONTH** after our notification, failing which, the defective product and all other accessories will be disposed of at our discretion.*

Chapter 5

Set up your Karaoke System Now! *(How to search for your suitable karaoke product on site)*

By now, you should be able to look for the right product you need that is suitable to you in order to set up your own Karaoke System ! How to look for?

On the site, go to MENU, go to "Product", go to "Category" and select your suitable product, Click in the product, you'll see the "Product Description", and "Demonstration Video". Don't miss all other related videos.

If you still want to know more, call us [416-291-3121](tel:416-291-3121) or text us at homekaraoke@hotmail.com. We are always here to help !

Or, if you have missed any previous videos, go to one of the "Category" sections, titled "[Talk on Karaoke Topics](#)"

Our Best Sellers

<h4>Karaoke Machine</h4>  <p>SK-2021</p>  <p>DCU-2017/8</p> <p>19.5"</p>  <p>TS-2022/3</p>	<h4>Sound System</h4>  <p>Pro. Speaker</p>  <p>NEW KA-2022/3B</p>  <p>Pro. Speaker</p>  <p>NEW PAS-2022/8</p>  <p>Remote</p>  <p>Wireless Mic</p>	<h4>Microphone</h4>  <p>NEW HKWM-2023</p>  <p>NEW PM-2023</p>
---	---	--

Chapter 6

Warranty, Return & Exchange Policy

Karaoke Singing Products are electronic and partying products. For hygienic and electronic safety reasons, we do not sell used products.

For hygienic reasons, microphones and other mobile devices are absolutely NOT subject to return and warranty.

Software program, song card and music quality are not subject to warranty, too.

Within 7 days from the Date of Purchase, only if the product is found with the manufacturer's defects, customers may ask for a full refund or a new replacement. Without any manufacturer's defect found, it may NOT be returned. ALL SALES ARE FINAL.

Within 7 days from the Date of Purchase, customers may ask for an exchange of products. Exchange is allowed only to a higher model with a higher price. In this case, customers will be required to pay the balance.

After 7 days from the Date of Purchase, there will be NO RETURN, NO EXCHANGE. Any manufacturer's defects found will be subject to One-Year Warranty, FREE repairing service, parts and labor.

Any product has been repaired by unauthorized personnel, any alteration, abuse, misuse or accidental damage will void the warranty.